

# GC2 BATTERY NOTICE

## Notice to all GC2 Owners -

The life of your GC2 battery and its ability to hold an adequate charge is dependent on a regular monthly routine to fully discharge and recharge the battery. Without a regular cyclical discharge/recharge routine, the GC2 battery's life expectancy can be compromised by as much as 75%.

Your GC2 battery should be fully discharged and recharged at least once a month. This includes batteries in storage, as well as batteries on GC2 units operating on continuous AC power.

Failure to abide by this routine may cause the battery to lose its ability to recharge or hold an adequate charge, and will require replacement at the customer's expense.

Unless directly authorized by Foresight Sports, DO NOT attempt to replace the battery in the device. Doing so will void all warranties, and may cause injury. For battery replacement authorization and instruction, please contact Foresight Sports. Product Warranty information can be viewed online at [www.foresightsports.com/productwarranty](http://www.foresightsports.com/productwarranty).

If you have any questions, please contact us at [innovation@foresightsports.com](mailto:innovation@foresightsports.com).

